

**SENA**



**MOMENTUM  
INC PRO**

**INTELLIGENT NOISE CONTROL™  
HELMET**

1.1.0

# RIDE CONNECTED

Blast your favorite tunes, talk over the intercom with your buddies, hear directions from your GPS and more, all through your Sena Momentum INC Pro, Intelligent Noise Control™ Helmet. With built-in Bluetooth® capabilities, Quad HD camera, HD speakers and a microphone using Advanced Noise Control™, technology has never felt so minimal or freeing.



Intelligent Noise Control™



Bluetooth® Integrated



Eight-Way Intercom



Quad HD Camera Integrated



Audio Multitasking™



Built-in Speakers and Mic



Music Sharing



1.6 Km (1.0 Mile) Intercom



Voice Command

# GETTING STARTED

1. This product comes with a Quick Start Guide, which is a basic version of the User's Guide. **A FULL VERSION OF THE USER'S GUIDE CAN BE DOWNLOADED AT [SENA.COM](http://SENA.COM).**
2. Update this product for free with the latest firmware to fully enjoy the new advanced features built into this product. Visit [sena.com](http://sena.com) to see how to update your product.
3. Users can follow Sena on Facebook, YouTube, Twitter and Instagram to receive the most up to date information on products, helpful tips and all other announcements regarding Sena products.

**SENA**



SENA Technologies, Inc.  
[sena.com](http://sena.com)

Customer Support: [support.sena.com](http://support.sena.com)


**MOMENTUM  
INC PRO**

**GETTING STARTED**

# QUICK START GUIDE

## How to Use This Guide

The legend and callouts are here to help you read the illustrations. New technology can be confusing, but we've created a simple way to perform actions using illustrations.




## Buttons

### Left Side


Center Button

(+) Button




# QUICK START GUIDE

## Right Side



## Top Side



# QUICK START GUIDE

## Icon Legend

**TAP 1x** Tap button the specified number of times

**HOLD 10s** Press and Hold button for the specified amount of time



"Hello"


**Audible prompt**

## Helmet Structure

### Left Side

Head Ventilation

Outer Shell



Chin Ventilation


Bluetooth System's Buttons

Face Shield

# QUICK START GUIDE

## Right Side

Ambient Mode Button




INC Button

DC Power Charging & Firmware Upgrade Port

## Top Side

MicroSD Card Slot



Camera System's Buttons

QHD Action Camera

# QUICK START GUIDE

## Bluetooth System's Buttons

### Left Side

#### (+) Button

Increase Volume  
Track Forward  
Scan Radio Stations  
Speed Dial

#### (-) Button

Decrease Volume  
Track Back  
FM Radio On/Off

Blue/Red/Green  
LED Lights

#### Center Button

Answer/End Phone Call  
Reject an Incoming Phone Call  
Start/End Intercom Conversation  
Play/Pause Music  
Enter Intercom Pairing Mode  
Enter Voice Configuration Settings


### Right Side

#### INC Button

Intelligent Noise  
Control™ On / Off


#### Ambient Mode Button

Ambient Mode  
On / Off



# QUICK START GUIDE

## Camera System's Buttons




### Camera Button

Camera Power  
On/Off  
Start/Stop Recording  
Factory reset  
Format SD Card

# QUICK START GUIDE

## Chinstrap

Gently pull the padded chinstrap outward and slide the helmet onto your head. Route the chinstrap under your chin, then thread it through both D-Rings. To fasten securely, thread chinstrap back through the D-Ring closest to your neck, and pull.



**Note:** Check the chinstrap's position and tension regularly to ensure proper fit.

# QUICK START GUIDE

## Basic Operation


### Powering On




### Powering Off



### Volume Up



### Volume Down




## Checking the Battery Level

### Visual Method



### Audible Method



"Battery level high/medium/low"

# QUICK START GUIDE

## Intelligent Noise Control™ (INC)

Sena's **Intelligent Noise Control** technology will protect your hearing while riding by reducing constant low-frequency sounds such as wind noise and high-frequency sounds such as face-to-face conversations, car horns and emergency sirens can be heard more clearly.

### INC On



"INC on"

### INC Off



"INC off"


## Ambient Mode

### Ambient On



"Ambient on"

### Ambient Off



"Ambient off"

# QUICK START GUIDE

## Voice Command



"Hello Sena"

Steps continued...



Speak a voice command from the table below

Voice Command	Function
"Music"	Play/Pause music
"FM radio"	FM Radio on/off
"Intercom [one, two, ... , nine]"	Start/End each intercom
"Speed dial [one, two, three]"	Speed dialing

## Bluetooth Pairing (Phone, MP3, GPS)

### Mobile Phone Pairing



CONFIG.  
MENU



HOLD  
12s



"Configuration menu"

Steps continued...



"Phone pairing"



LED  
STATUS

Alternating blue and red flashing lights indicate **device is now discoverable.**



NAVIGATE  
FORWARD  
1X



TAP  
1x




PIN  
NUMBER

0 0 0 0


# QUICK START GUIDE

## Mobile Phone


### Answer a Call



### End/Reject a Call



### Make Call with Voice Dialer




## Music Controls


### Play/Pause



### Next Track




### Previous Track



# QUICK START GUIDE


## Camera Controls

### Camera On




"Camera on"

### Start Recording




"Recording"

### Camera Off




"Camera off"

### Stop Recording




"Recording stop"

### Format SD Card



"Format SD card"



EXECUTE



"Format SD card completed"

### Note:

- You cannot record videos without a microSD card.
- Your micro SD card needs to be formatted using the camera system before using the camera.
- microSD cards up to 64GB and Class 10 or higher cards are compatible.

# QUICK START GUIDE

## Intercom

Up to nine other people can be paired with the helmet for Bluetooth intercom conversations.

### Pairing Headset A with Headset B



"Intercom pairing"



LED STATUS

Flashing blue LED confirms **intercoms are paired.**


### Start/End Intercom with Headset B



# QUICK START GUIDE


## Group Intercom

### Start Group Intercom



*"Group intercom"*

### End Group Intercom



*"Group intercom terminated"*




**Note:** You can use Group Intercom after saving your own group using the Sena Smartphone App. Please refer to the helmet User's Guide for more details.

# QUICK START GUIDE


## Radio

### FM Radio On




"FM on"

### FM Radio Off




"FM off"

### Seek Forward



SEEK  
FORWARD

### Seek Backward




SEEK  
BACKWARD

# QUICK START GUIDE


## Bluetooth System Configuration Menu

### Accessing the Configuration Menu





"Configuration menu"

### Navigating between Menu Options



"[Menu prompt]"

### Execute Menu Options



"[Menu prompt]"

## Camera System Configuration Menu

You can change the camera configuration settings of the camera system through the Sena Camera App.

# QUICK START GUIDE

## Sena Device Manager

The Sena Device Manager allows you to upgrade the Bluetooth system's firmware and configure its settings directly from your PC or Apple computer. Using this software, you can assign speed dial presets, FM radio station presets and more. For more information on downloading the Sena Device Manager, please visit [sena.com](http://sena.com).

## Sena Smartphone App

The Sena Smartphone App allows you to configure the Bluetooth system's settings, as well as access the User's and Quick Start Guides. To do so, pair your mobile phone with your headset by following the instructions in the "Bluetooth Pairing (Phone, MP3, GPS)" section in this quick start guide. Run the Sena Smartphone App and configure the settings directly from your smartphone. You can download the Sena Smartphone App for Android and Apple operating systems from [sena.com](http://sena.com).



Download on the  
**App Store**



GET IT ON  
**Google Play**

# QUICK START GUIDE

## Sena Camera App

The Sena Camera App allows you to see a live preview from the camera, manage recorded videos as well as configure the video settings using the built-in WiFi feature on camera system. When the camera system and the Sena Camera App are connected, the camera system is synchronized with the smartphone's date and time. To do so, connect your mobile phone with the camera system by following the instructions provided on the Sena Camera App. You can download the Sena Camera App for Android and Apple operating systems from [sena.com](http://sena.com).



Download on the  
**App Store**



GET IT ON  
**Google Play**

# QUICK START GUIDE

## Camera Firmware Upgrade Guide

1. Remove your microSD card from the MicroSD Card Slot on the helmet.
2. Connect your microSD card to a PC or Apple computer using an SD card adapter or a USB SD card reader.
3. Download the latest firmware from [sena.com](https://www.sena.com).
4. Copy the firmware file to the root folder of your microSD card.
5. Remove your microSD card from your PC or Apple computer and insert it into the MicroSD Card Slot on the helmet.
6. Power on the camera system. The firmware will update automatically.
7. Power off the camera system when the update is complete and the Camera LED turns from green to red. Power on the camera system to start recording your videos.

**Note:** An SD card adapter or a USB SD card reader are not included in the package.


# QUICK START GUIDE

## Troubleshooting

### Factory Reset for Bluetooth system



"Configuration menu"



NAVIGATE  
BACKWARD  
2X




"Factory reset"




EXECUTE

### Fault Reset for Bluetooth system




**Note:** Fault Reset will not restore the Bluetooth system to factory default settings.

### Factory Reset for Camera system



"Factory reset"



EXECUTE



"Camera reset"

# QUICK REFERENCE

TYPE	OPERATION	BUTTON COMMANDS
 Basic Operations	Power on/off	  
	Volume up/ Volume down	 (TAP 1x)  (TAP 1x)
	Voice command	 "Hello Sena"
	INC (Intelligent Noise Control) On/Off	 
	Ambient Mode On/Off	 

# QUICK REFERENCE

TYPE	OPERATION	BUTTON COMMANDS
 Mobile Phone	Answer phone call	 
	End/Reject phone call	 
	Voice dial	 
	Speed dial	 
 Music	Play/Pause music	 
	Track forward	 
	Track backward	 
 Camera	Camera On	 
	Camera Off	 
	Start/Stop recording	 
	Format SD card	   

# QUICK REFERENCE

TYPE	OPERATION	BUTTON COMMANDS
 FM Radio	FM radio on/off	 
	Seek forward	 
	Seek backward	 
 Intercom	Intercom pairing	   
	Start/End intercom	 
	End all intercoms	 
	Start group intercom	  
	End group intercom	  